

HAND DELIVERED

06.01457  
APR 13 2006

UTAH DIVISION OF  
SOLID & HAZARDOUS WASTE

CLASS 2 MODIFICATION

TO THE

TOCDF RCRA PERMIT

REQUEST NUMBER: TOCDF-MDM-02-0836

REQUEST TITLE: Froth Collection System for MDMs

EPA ID: UT 5210090002

TO: UTAH DIVISION OF SOLID AND HAZARDOUS WASTE  
1460 WEST 288 NORTH  
P. O. BOX 144880  
SALT LAKE CITY, UTAH 84114-4880

**TITLE: FROTH COLLECTION SYSTEM FOR MDMS**

**CLASS: Class 2 Modification - 40 CFR 270.42 (d)**

## **INDEX**

### **Section**

- A. ....DESCRIPTION OF CHANGES**
- B. ....PERMIT CHANGE PAGES**
- C. .... FACILITY IMPACT**
- D. .... HEALTH/ENVIRONMENTAL IMPACT**
- E. .... JUSTIFICATION**
- F. .... REFERENCE DRAWINGS**
- G. .... NOTICE TO MAILING LIST AND NEWSPAPER PUBLISHER**

<b>A: DESCRIPTION OF CHANGES</b>
----------------------------------

REQUEST TO CLASSIFY AS A CLASS 2 MODIFICATION

In accordance with 40 CFR 270.42(d)(1), the Tooele Chemical Agent Disposal Facility (TOCDF) requests a determination that this modification should be reviewed and approved as a Class 2 Modification Request to the TOCDF Resource Conservation and Recovery Act (RCRA) Permit. This modification request contains in Section E the information necessary to justify the requested classification.

SCOPE OF THIS MODIFICATION REQUEST

This scope of this modification request includes only the installation of the newly-designed Froth Collection System onto the existing Multipurpose Demilitarization Machines (MDMs)—which are currently-permitted 40 CFR 264 Subpart X “Miscellaneous Treatment Units”. The treatment of 4.2-inch Mustard mortars at the MDMs and the Metal Parts Furnace (MPF) is not within the Baseline Mustard Tons campaign and will be the subject of a later Class 3 RCRA modification request. This Froth Collection System modification is being requested now in order to install the necessary hardware before the Mustard Baseline campaign begins, thereby taking advantage of the recently decontaminated MPB.

BACKGROUND

TOCDF has completed destruction of warfare munitions containing GB (Sarin) and VX. TOCDF is now scheduled to begin the destruction of munitions and containers filled with the chemical warfare agents designated as H, HD and HT (collectively referred to as “Mustard” blister agent). The Mustard “campaign” is the third and final agent demilitarization campaign TOCDF is to undertake.

The DCD chemical weapons stockpile includes approximately 63,500 4.2-inch mortar rounds. Experience at the Johnston Island JACADS has shown that some of the mustard-containing mortars may have experienced age-related degradation resulting in a susceptibility to effervescence when the agent cavity is breached. Such effervescing munitions at JACADS have been described as “champaign mortars” in reference to their effervescent or “frothing” tendency when the burster well was removed. Previously-processed GB and VX-containing projectiles at TOCDF did not exhibit the “frothing” tendency that is anticipated with the upcoming Mustard mortars.

The current design configuration of the MDM Pull and Drain station includes drip pans in order to limit agent contamination of the machinery and other surfaces. The drip pans include small drains and suction lines connected directly to the Agent Collection system piping at the suction side of the agent transfer pump. However, the Pull and Drain Station, as currently configured, would not be able to limit agent contamination

that would result from a frothing agent that might run down the sides of the mortar and onto machinery and equipment surfaces.

In an effort to minimize frothing-related agent contamination of machinery and equipment, a "froth collection system" was designed and tested at the Chemical Demilitarization Training Facility (CDTF) in Edgewood, Maryland. The froth-collection system design was based on operational experience gained at JACADS.

#### Current Design Operation

Before being drained at the MDMs, the 4.2-inch mortars will have their burster/fuze assemblies removed in the Explosive Containment Room (ECR). After exiting the ECR, the mortars will be oriented vertically upright and transferred to the Munitions Processing Bay (MPB) where they will be placed on one of three Multi-Purpose Demilitarization Machines (MDMs). In order to access the agent in the mortar's agent cavity, the MDM's Pull and Drain Station machinery will raise up so that the mortar's nose is in contact with the stop plate prior to removal of the burster well. As was experienced at JACADS, as soon as the burster well was unseated, the agent cavity became exposed to atmospheric pressure, allowing dissolved gases in the liquid agent to effervesce, frothing liquid agent upward and out of the mortar.

#### Problem with Current Design Operation

Although Mustard 4.2-inch mortars have never been processed at the TOCDF's MDMs, it is anticipated that the same effervescing or frothing problem will be encountered as was experienced at JACADS. The problems experienced at JACADS, if not accounted for through design changes, is expected to occur at TOCDF.

#### Modified MDM Configuration Objectives

The modified Pull and Drain Station is designed to:

- 1) Minimize the escape of frothed agent from the ACS system to the MPB's room's sumps and the SDS system
- 2) Minimize liquid agent contamination of the mortar's outer surface, machinery, equipment, room surfaces, and LSS air hoses
- 3) Reduce airborne agent concentrations in the MPB HVAC flow that would result from increased liquid Mustard contamination.

### MDM Mortar Froth Collection System Description

The MDM froth collection system consists of six key elements:

1) A modified stop plate

The mortar is raised by the lift cylinder until it is firmly in contact with the stop plate, which holds the mortar's body down while the burster well is removed upward. The existing stop plate will be replaced with a new stop plate with a radial hole bored and tapped to provide a suction pathway from the inner hole that immediately surrounds the burster well press fit. The radial hole thus is at the location where the froth will begin to exit the mortar. To accommodate the radial hole, the new stop plate will be made thicker than the previous stop plate.

2) A froth dam

The froth dam is an open-ended canister facing upward that will serve as a temporary chamber accumulating froth until the suction is capable of drawing the froth away into the agent collection system.

3) A froth shield

The froth shield serves to redirect froth ejected out of the mortar downward into the froth dam.

4) Frame spacer plates

Due to the additional thickness of the stop plate, the entire pull and drain framework will need to be raised an additional 1-3/8" to restore the mortar's overhead clearance.

5) A modified drip pan cylinder hanger bracket

Because the existing drip pan hydraulic cylinder is mounted to the pull and drain framework, which will be raised, a lengthened cylinder mounting bracket will be required to account for the modified overall dimensions.

6) An air actuated ball valve

Tubing will be attached to the modified stop plate's radial hole running to the agent pump suction piping in an identical manner as the drip pans' drain tubing. Because the suction will be activated at key steps in the pull and drain sequence, an air actuated ball valve will be installed within the suction tubing. A solenoid valve will control actuation air (instrument air) to the ball valve.

PERMIT WORDING CHANGES

Attachment 14 "Demilitarization Miscellaneous Treatment Units":

Add the froth collection feature to the description of the MDM's pull and drain operation.

Attachment 17

Add the MDM pull and drain stations' agent-containing froth collection system, as well as the existing drip pan piping components to the equipment lists for 40 CFR 264 Subpart BB – "Air Emissions Standards for Equipment Leaks".

**B: RCRA PERMIT CHANGE PAGES**

**CHANGE PAGES IN BODY OF PERMIT:**

None

**CHANGE PAGES IN ATTACHMENTS OF PERMIT:**

Attachment 14, "Demilitarization Miscellaneous Treatment Units"

Page 46

Attachment 17, "Equipment Lists"

Pages 4, 5, 6 and 7

**CHANGES TO DRAWINGS IN PERMIT**

**P&IDs**

- 1) TE-1-D-521 Sheet 1 of 1, Agent Collection System PHS-MDM-101
- 2) EG-01-D-521 Sheet 1 of 2, Agent Collection System PHS-MDM-102
- 3) EG-01-D-521 Sheet 2 of 2, Agent Collection System PHS-MDM-103

rotated so that the first munition goes to Station 3 and the second moves to Station 2. Another munition is placed in the Load/Unload Station and the table is rotated again. Eventually, the MDM is operated so that all six stations have a munition (except when the munitions tray does not have enough remaining unprocessed munitions to deliver to the MDM). Stations 2 and 3 do not perform any operations.

- 14.5.2.2.6 Station 4 is normally used as the Bore Station. It is designed to bore out welded or stuck burster wells. This station is not expected to be used very frequently because most of the munition burster wells were assembled with the press fit method. If a munition requires boring, a clamp cylinder extends and holds the munition in place while the boring head (consisting of an appropriately sized spade drill bit) bores vertically down through the top of the munition. The bore head is raised and lowered by a feed cylinder that contains the bore head drill and motor and is mounted on four vertically-mounted bolster rods. As an alternative, this position can also be configured as a Nose Closure Removal/Burster Detection Station, which may be used to process projectiles received at the TOCDF without bursters. At this station, the nose plugs will be removed and the absence of a burster will be confirmed.
- 14.5.2.2.7 Station 5 is the Pull and Drain Station. It is designed to remove the burster well, thus providing access to the agent-filled cavity in the munition, and then to drain the agent from the munition. Upon entering Station 5, the munition is lifted slightly and held in place while the carriage assembly, which contains a collet assembly and pull cylinders, is lowered so that the collet assembly enters the munition. The collet expands to grip the burster well, and the pull cylinders extend to raise the collet assembly and the burster well from the munition. During burster well removal, a suction may be applied at the munition's nose in order to contain within the ACS system froth that may develop.
- 14.5.2.2.8 After the burster well is removed from the munition, the munition is shifted horizontally into the Drain Station position. A drain tube, which consists of a straight, hollow, steel tube, is lowered into the munition, and the ACS removes the agent from the munition. Under normal operations, it is expected that some of the agent will not be removed by this process. After draining the munition, the drain tube is retracted, the munition returns to the Pull Station, and the burster well is placed back in the munition (or, for some munition types, it is dropped into the burster well chute). Station 5 contains a drip pan to collect residual agent that may drip from the burster well and agent drain tube.
- 14.5.2.2.9 Station 6 is the Crimp Station. It is designed to remove the burster well from the munition and crimp it. Crimping the burster well deforms it so that it no longer seats completely in the munition when replaced. The resulting gap between the burster well and the agent cavity allows a more thorough thermal combustion of the agent heel in the MPF. The burster well is removed from the munition by the burster well gripper assembly. The burster well crimp jaw closes around the burster and deforms it. A strip cylinder is used to remove the burster well from the gripper assembly, where it may become stuck during compression.
- 14.5.2.2.10 The munition is rotated to Station 1 after it is drained and the crimped burster well is placed back into the munition (except for those munitions where the burster well is discarded at Station 5). A burster well detector sensor located at Station 1 checks for the presence of a burster well. If a burster well is not detected, the PPM places the munition



Table 17-1: ACS Equipment Subject to 40 CFR 264 Subpart BB Requirements<sup>1</sup>

Haz Waste Mgmt Unit	Equipment Tag No.	Location <sup>2</sup>	Equipment Type	Organic Content (wt%)	Physical State	Method of Compliance with the Standards
ACS - drain from BDS	51-1"-V-22	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	SP-159	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	ACS-PUMP-115	MPB	Pump	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	SP-159	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	51-1"-V-23	MPB	Valve to hose with quick disconnect male w/ dust cap/Teflon gasket.	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	51-1"-V-24	MPB	Check Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	1"-V-23A	MPB	Valve (blinded)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	3/4"-V-9020D	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	FV-20	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from BDS	1"-V-26	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	MDM 101 Drain Tube Flex Hose	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-74	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-TANK-108	MPB	Flanged Connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1/2"-V-53D	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1/2"-V-53E	MPB	Valve (sampling)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-75	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-FILT-105	MPB	Flanged Connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	PI-73	MPB	Flanged Connection w/ isolation valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1 1/2"-V-50	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-51	MPB	Valve (w/quick disconnect)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-54	MPB	Valve (w/quick disconnect)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-58	MPB	Check Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-53	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-PUMP-105	MPB	Pump	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)

Table 17-1: ACS Equipment Subject to 40 CFR 264 Subpart BB Requirements<sup>1</sup>

Haz Waste Mgmt Unit	Equipment Tag No.	Location <sup>2</sup>	Equipment Type	Organic Content (wt%)	Physical State	Method of Compliance with the Standards
ACS - drain from MDM	Flex Hose	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-77	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-73B	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	LIT-73	MPB	Flanged Connection	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9109	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (froth collection)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9077	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9078	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (burster well drip pan)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (drain tube drip pan)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	MDM 102 Drain Tube Flex Hose	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-84	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-TANK-106	MPB	Flanged connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1/4"-V-83D	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1/4"-V-83E	MPB	Valve (sampling)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-85	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-FILT-106	MPB	Flanged connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	PI-81	MPB	Flanged Connection w/ isolation valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex hose	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1 1/2"-V-74	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-75	MPB	Valve (w/quick disconnect)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-76	MPB	Valve (w/quick disconnect)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-79	MPB	Check Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-77	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	SP-159	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-PUMP-106	MPB	Pump	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	SP-159	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-87	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)

Table 17-1: ACS Equipment Subject to 40 CFR 264 Subpart BB Requirements<sup>1</sup>

Haz Waste Mgmt Unit	Equipment Tag No.	Location <sup>2</sup>	Equipment Type	Organic Content (wt%)	Physical State	Method of Compliance with the Standards
ACS - drain from MDM	XV-83B	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	LIT-83	MPB	Flanged connection	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9110	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (froth collection)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9087	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9088	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (burster well drip pan)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (drain tube drip pan)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	MDM 103 Drain Tube Flex Hose	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-94	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-TANK-107	MPB	Flanged connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1/4"-V-93D	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1/4"-V-93E	MPB	Valve (sampling)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-95	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-FILT-107	MPB	Flanged connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	PI-93	MPB	Flanged Connection w/ isolation valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex hose	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1 1/2"-V-90	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-91	MPB	Valve (w/quick disconnect)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-94	MPB	Valve (w/quick disconnect)	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-98	MPB	Check Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	1"-V-93	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	SP-159	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	ACS-PUMP-107	MPB	Pump	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	SP-159	MPB	Flex connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-97	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-93B	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	LIT-93	MPB	Flanged connection	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)

Table 17-1: ACS Equipment Subject to 40 CFR 264 Subpart BB Requirements<sup>1</sup>

Haz Waste Mgmt Unit	Equipment Tag No.	Location <sup>2</sup>	Equipment Type	Organic Content (wt%)	Physical State	Method of Compliance with the Standards
ACS - drain from MDM	XV-9111	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (froth collection)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9097	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	XV-9098	MPB	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (burster well drip pan)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS - drain from MDM	Flex Hose (drain tube drip pan)	MPB	Flex Connector	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-82	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-76	TOX	Check Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	1 1/2"-V-81	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	1-1/2"-V-77	TOX	Check Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	LV-84	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-78	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	LE-91	TOX	Flange connection	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	LIT-93	TOX	Flange connections w/ chemical seals	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	LE-95	TOX	Flange connection w/ plug drain valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	PSE-162	TOX	Rupture Disc w/ Flange connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	PSV-161	TOX	Pressure Relief Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-87	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	1-1/2"-V-85	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	1-1/2"-V-86	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-81	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-84	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	2"-V-79	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	LV-97	TOX	Valve	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	PDIT-099	TOX	Flange connections w/ chemical seals	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)
ACS Tanks	SP-102	TOX	Flange connections	> 10%	Liquid	R315-8-18 (40 CFR 264.1058 and 1059)

<b>C: FACILITY IMPACT</b>
---------------------------

Physical Facility Impacts

The new fully-tested froth collection assembly will be installed at each of the three MDMs. In addition, the Process computer code will be revised to incorporate the automatic operation of an electrical solenoid valve that provides actuation air to the ball valve within the agent suction line.

Administrative Facility Impacts

In accordance with the site Configuration Management Process for engineering changes, Plant procedures, training plans, drawings and miscellaneous documents will be revised to incorporate the new froth collection equipment.

Facility Personnel Impacts

Additional toxic entries by facility personnel will be required to install the froth collection equipment and perform various post-installation testing. Once fully installed and tested, it is anticipated that the operation of the MDM will not require more toxic entries than would have been required to support the previous MDM configuration. The automated operation of the new MDM pull and drain froth collection system will not require any additional operations personnel effort.

**D: HEALTH/ENVIRONMENTAL IMPACT**

There are no adverse health or environmental impacts associated with this modification, based on the following:

- 1) This modification will enable TOCDF to minimize agent contamination of plant equipment from the possibility of excessive frothing of Mustard.
- 2) This modification reduces the potential for agent contamination of Life Support System (LSS) hoses whenever toxic area entrant personnel are working in the vicinity.
- 3) This modification reduces airborne concentrations of Mustard vapor that may result from drippage or spillage.

**E: JUSTIFICATION**

CLASS 2 MODIFICATION TO RCRA PERMIT

In accordance with 40 CFR 270.42(d)(1), the Tooele Chemical Agent Disposal Facility (TOCDF) has requested a determination that this modification should be reviewed and approved as a Class 2 Modification Request.

As opposed to Class 1 and Class 3 modifications, Class 2 modifications apply to changes that are necessary to enable a permittee to respond in a timely manner to "common variation of wastes" and to "technological advancements". Class 1 modifications apply to minor changes that keep the permit current, whereas Class 3 modifications "substantially alter the facility or its operation".

Common Variations of Wastes

TOCDF has previously treated 105-mm and 155-mm projectiles at the MDMs. The existing design of the MDM does not have any provisions for capturing agent that may foam or otherwise be expelled up and out of the mortar when the agent cavity is opened up for draining. None of the projectiles previously treated on the TOCDF MDMs exhibited a tendency to froth or foam. Experience at JACADS revealed that some of the 4.2-inch Mustard mortars have experienced internal pressurization. This pressurization resulted in a frothing of the Mustard contents when the burster well press fit was initially loosened. TOCDF is preparing to treat the same types of Mustard mortars that were treated at JACADS.

Technological Advancements

The newly-designed MDM froth collection system has features that did not exist on the previous MDMs. The MDM froth collection system was designed based upon operating experience at JACADS with the Mustard-containing munitions.

Substantial Alteration of the Facility or Operation

The overall objective of the MDM remains the same, regardless of the addition of the froth collection feature. The modified MDM design will function as effectively with non-pressurized or non-frothing mortars.

- 1) The MDM pull and drain station will pump liquid agent from the mortar, agent drippage from the drip pans, and agent froth that may collect in the froth collection system.

RCRA Modification Request TOCDF-MDM-02-0836

- 2) The liquid agent within the mortar will be pumped to the Agent Quantification System (AQS) prior to transfer to the ACS tanks for ultimate destruction in the LIC primary chamber.
- 3) The liquid agent captured on the drip pans and within the froth collection system will be transferred directly to the ACS for destruction in the LIC primary chamber.

Because the installation of the froth collection system does not substantially alter the facility or its operation, this request does not meet the intent of a Class 3 modification.

Attachment 14, "Demilitarization Miscellaneous Treatment Units"

A one-sentence description of the froth collection feature has been added to the MDM's operation.

Attachment 17, "Equipment Lists"

The froth collection system is designed to contain chemical agent, a hazardous waste with greater than 10% organic content. As such, the froth collection system is subject to the rules of 40 CFR 264 Subpart BB "Air Emissions Standards for Equipment Leaks".

Attachment 17 of the RCRA permit contains a complete listing of ACS equipment subject to Subpart BB. In addition to the new froth collection system, equipment associated with the existing drip pans was also added to the equipment lists.



<b>F:    REFERENCE DRAWINGS</b>
---------------------------------

- 1) EG&G Drawing TE-1-D-521 Sheet 1  
P&ID - MDB Agent Collection PHS-MDM-101
- 2) EG&G Drawing EG-01-D-521 Sheet 1  
P&ID - MDB Agent Collection PHS-MDM-102
- 3) EG&G Drawing EG-01-D-521 Sheet 2  
P&ID - MDB Agent Collection PHS-MDM-103
- 4) EG&G Drawing EG-01-M-5102 Sheet 2  
MDB ACS-PHS-MDM-101 Assembly
- 5) EG&G Drawing EG-01-M-5102 Sheet 1  
MDB ACS-PHS-MDM-102 Assembly
- 6) EG&G Drawing EG-01-M-5114 Sheet 1  
MDB ACS-PHS-MDM-103 Assembly
- 7) General Physics Corp. Drawing 45-0221 Sheet 1  
Assembly Drawing – Froth Collection - MDM
- 8) General Physics Corp. Drawing 45-0287 Sheet 1  
Modified Stop Plate 4.2 Mortar – Froth Collection System – MDM Punch [sic]  
& Drain Station
- 9) General Physics Corp. Drawing 45-0321 Sheet 1  
Froth Dam and Froth Cylinder Hanger - MDM
- 10) General Physics Corp. Drawing 45-0329 Sheet 1  
MDM Froth Shield for 4.2 Mortar
- 11) General Physics Corp. Drawing 45-0324 Sheet 1  
Frame Spacer for Froth Collection – MDM Punch [sic] and Drain Station



1. ALL INSTRUMENT AND VALVE TAG NUMBERS ARE PREFIXED WITH 04-S1  
(EXCEPT AS NOTED).
2. FOR LOGGING, SYMBOLS, AND GENERAL NOTES, SEE  
DRAWING TI-00-0-3001.
3. WORKSIDE LENGTH OF ALL AGENT PIPING.
4. PCV AND FILTER/REGULATOR TO BE SUPPLIED WITH THE PUMP.
5. ALL DISINTEGRATION TO BE SUPPLIED WITH THE ADS  
VERIFICATION TANK.
6. ADS VERIFICATION TANKS ACS-TANK-105 OR ACS-TANK-108 WILL  
BE USED AS REQUIRED FOR THE MAINTENANCE TIME BEING PROCESSED.
7. INSTALL SPECTACLE BLIND WHEN NOT IN USE.
8. OPTIONAL DECOR TAP.

----- FUTURE FROTH COLLECTION FOR HD CAMPAIGN

EG-01 0-5114 MOB ACS PHS-MON-103 ASSEMBLY  
EG-01 0-5102 SHT.1 MOB ACS PHS-MON-102 ASSEMBLY  
EG-01 0-5102 SHT.2 MOB ACS PHS-MON-101 ASSEMBLY  
EG-01 0-521 SHT.1 MOB AGENT COLLECTION SYSTEM PHS-MON-102 PA  
EG-01 0-521 SHT.2 MOB AGENT COLLECTION SYSTEM PHS-MON-103 PA  
EG-01 0-5101 SHT.2 MOB ACS PHS-MON-102 INSTALLATION DETAILS  
EG-01 0-5101 SHT.3 MOB ACS PHS-MON-101 GENERAL ARRANGEMENT  
EG-01 0-5115 SHT.1 MOB ACS PHS-MON-103 INSTALLATIONS DETAILS  
EG-01 0-5115 SHT.2 MOB ACS PHS-MON-103 PIPE SPOOLS DETAILS

[illegible]

NO.	DESCRIPTION	DATE	BY	CHK	APP
1	DESIGN				
2	DESIGN				
3	DESIGN				
4	DESIGN				
5	DESIGN				
6	DESIGN				
7	DESIGN				
8	DESIGN				
9	DESIGN				
10	DESIGN				
11	DESIGN				
12	DESIGN				
13	DESIGN				
14	DESIGN				
15	DESIGN				
16	DESIGN				
17	DESIGN				
18	DESIGN				
19	DESIGN				
20	DESIGN				
21	DESIGN				
22	DESIGN				
23	DESIGN				
24	DESIGN				
25	DESIGN				
26	DESIGN				
27	DESIGN				
28	DESIGN				
29	DESIGN				
30	DESIGN				
31	DESIGN				
32	DESIGN				
33	DESIGN				
34	DESIGN				
35	DESIGN				
36	DESIGN				
37	DESIGN				
38	DESIGN				
39	DESIGN				
40	DESIGN				
41	DESIGN				
42	DESIGN				
43	DESIGN				
44	DESIGN				
45	DESIGN				
46	DESIGN				
47	DESIGN				
48	DESIGN				
49	DESIGN				
50	DESIGN				
51	DESIGN				
52	DESIGN				
53	DESIGN				
54	DESIGN				
55	DESIGN				
56	DESIGN				
57	DESIGN				
58	DESIGN				
59	DESIGN				
60	DESIGN				
61	DESIGN				
62	DESIGN				
63	DESIGN				
64	DESIGN				
65	DESIGN				
66	DESIGN				
67	DESIGN				
68	DESIGN				
69	DESIGN				
70	DESIGN				
71	DESIGN				
72	DESIGN				
73	DESIGN				
74	DESIGN				
75	DESIGN				
76	DESIGN				
77	DESIGN				
78	DESIGN				
79	DESIGN				
80	DESIGN				
81	DESIGN				
82	DESIGN				
83	DESIGN				
84	DESIGN				
85	DESIGN				
86	DESIGN				
87	DESIGN				
88	DESIGN				
89	DESIGN				
90	DESIGN				
91	DESIGN				
92	DESIGN				
93	DESIGN				
94	DESIGN				
95	DESIGN				
96	DESIGN				
97	DESIGN				
98	DESIGN				
99	DESIGN				
100	DESIGN				

NOTES:

1. ALL INSTRUMENT AND VALVE TAG NUMBERS ARE PREFIXED WITH 04-51.
2. ALL INSTRUMENT AND VALVE TAG NUMBERS ARE PREFIXED WITH 04-51.
3. SEE LEGEND, SYMBOLS, AND GENERAL NOTES. SET
4. DRAINAGE LENGTH OF ALL AGENT PIPING.
5. SET AND FILL CAPACITATION TO BE SUPPLIED WITH THE PUMP.
6. ALL INSTRUMENTATION TO BE SUPPLIED WITH THE AGS
7. VERIFICATION TANKS AGS-TANK-100 OR AGS-TANK-100 WILL
8. BE USED AS REQUIRED FOR THE MAINTENANCE TYPE BEING PROCESSED.
9. VERTICAL SPECIFICATIONS BLIND WHEN NOT IN USE.
10. TOPDOWN SECOND TAP.

LEGEND:

— FUTURE

REFERENCE DRAWINGS:

- EG-01-0-5114 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-1 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-2 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-3 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-4 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-5 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-6 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-7 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-8 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-9 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-10 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-11 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-12 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-13 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-14 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-15 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-16 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-17 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-18 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-19 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-20 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-21 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-22 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-23 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-24 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-25 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-26 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-27 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-28 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-29 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-30 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-31 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-32 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-33 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-34 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-35 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-36 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-37 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-38 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-39 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-40 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-41 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-42 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-43 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-44 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-45 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-46 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-47 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-48 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-49 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-50 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-51 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-52 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-53 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-54 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-55 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-56 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-57 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-58 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-59 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-60 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-61 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-62 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-63 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-64 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-65 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-66 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-67 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-68 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-69 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-70 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-71 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-72 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-73 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-74 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-75 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-76 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-77 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-78 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-79 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-80 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-81 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-82 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-83 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-84 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-85 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-86 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-87 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-88 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-89 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-90 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-91 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-92 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-93 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-94 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-95 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-96 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-97 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-98 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-99 MIN AGS PMS-MEM-103 ASSEMBLY
- EG-01-0-5112 SHUT-100 MIN AGS PMS-MEM-103 ASSEMBLY

NO.	REVISION	DATE	BY	CHK	APP
23A	REVISED FOR CONSTRUCTION				
23	REVISED AS BUILT				
22	REVISED AS BUILT				
21	REVISED AS BUILT				
20	REVISED AS BUILT				
19	REVISED AS BUILT				
18	REVISED AS BUILT				
17	REVISED AS BUILT				
16	REVISED AS BUILT				
15	REVISED AS BUILT				
14	REVISED AS BUILT				
13	REVISED AS BUILT				
12	REVISED AS BUILT				
11	REVISED AS BUILT				
10	REVISED AS BUILT				
9	REVISED AS BUILT				
8	REVISED AS BUILT				
7	REVISED AS BUILT				
6	REVISED AS BUILT				
5	REVISED AS BUILT				
4	REVISED AS BUILT				
3	REVISED AS BUILT				
2	REVISED AS BUILT				
1	REVISED AS BUILT				

1. DEPARTMENT OF THE ARMY  
2. ENGINEERING DISTRICT SACRAMENTO  
3. CORPS OF ENGINEERS  
4. SACRAMENTO, CALIFORNIA

5. TANKS AND DEPOSITS  
6. CHEMICAL STOCKPILE DISPOSAL PROGRAM  
7. AGENT COLLECTION SYSTEM PMS-MEM-103  
8. PIPING & INSTRUMENT DIAGRAM

9. DRAWN BY: [Name]  
10. CHECKED BY: [Name]  
11. DESIGNED BY: [Name]  
12. APPROVED BY: [Name]

13. SCALE: NO SCALE  
14. DATE: EG-01-0-521  
15. SHEET: 23A

NOTE:  
REFER TO DRAWING TE-1-0-521  
PMS-MEM-101 AND EG-01-0-521  
SHEET 2 PMS-MEM-103 FOR  
INFORMATION ON AGENT  
COLLECTION SYSTEM





1. ALL INSTRUMENT AND VALVE TAG NUMBERS ARE PREFIXED WITH 04-S4-  
EXCEPT FOR NOTES.
2. FOR LEGEND, SYMBOLS, AND GENERAL NOTES, SEE  
DRAWING TE-00-0-1001.
3. UNKNOWN LENGTH OF ALL AGENT PIPING.
4. PCV AND FILTER/REGULATOR TO BE SUPPLIED WITH THE PUMP.
5. ALL INSTRUMENTATION IS TO BE SUPPLIED WITH THE ADS  
VERIFICATION TANK.
6. ADS VERIFICATION TANKS AGES-TANK-107 OR AGES-TANK-110 WILL  
BE USED AS REQUIRED FOR MAXIMUM TIME BEING PROCESSED.
7. INSTALL SPECTACLE BLIND WHEN NOT IN USE.
8. 10%DOWN DECOR TAP.

1990s. **FUTURE**


EG-01-0-5114 MOB ACS PMS-MEM-101 ASSEMBLY  
EG-01-0-5102 SH1.1 MOB ACS PMS-MEM-102 ASSEMBLY  
EG-01-0-5102 SH2.2 MOB ACS PMS-MEM-101 ASSEMBLY  
EG-01-0-5121 SH1.1 MOB AGENT COLLECTION SYSTEM PMS-MEM-102 PAID  
TE-01-0-521 MOB AGENT COLLECTION SYSTEM PMS-MEM-101 PAID  
EG-01-0-5101 SH1.2 MOB ACS PMS-MEM-102 INSTALLATION DETAILS  
EG-01-0-5101 SH1.3 MOB ACS PMS-MEM-101 GENERAL ARRANGEMENT  
EG-01-0-5115 SH1.1 MOB ACS PMS-MEM-103 INSTALLATION DETAILS  
EG-01-0-5115 SH1.2 MOB ACS PMS-MEM-103 PIPE SPOOLS DETAILS

25A	REVISED FOR CONSTRUCTION		
25	REVISED AS BUILT	06/06/02	180
24	REVISED	06/06/04	058
23	REVISED	11/06/03	056
22	REVISED PER CONSTRUCTION	11/06/02	053
21	REVISED PER CONSTRUCTION	01/01/01	0
20	REVISED PER CONSTRUCTION	11/06/00	010
19	REVISED PER CONSTRUCTION	06/06/00	0
Symbol	Description	Date	Approved

Revisions	
DEPARTMENT OF THE ARMY PROGRAM MANAGER FOR CHEMICAL DECONTAMINATION	US ARMY ENGINEER DISTRICT SACRAMENTO CORPS OF ENGINEERS SACRAMENTO, CALIFORNIA

ABSTRACT PROJECT: GROUND - WARTLEY, MD		US Army Corps of Engineers		TOGGLE ARMY DET	
 <b>EG&amp;G</b> a Division of TRC		 <b>FPM</b>		TOGGLE - U	
<b>CHEMICAL STOCKPILE DISPOSAL PROGRAM</b> MAINTENANCE DEMILITARIZATION BUILDING AIRCRAFT COLLECTION SYSTEM PHS-MDM-103 <b>PIPING &amp; INSTRUMENT DIAGRAM</b>					
Drawn by: J. BERKSHIRE	Date: 04/15/78	EG&G Approved: R. H. JONES	Scale: NO SCALE	Sheet number: EG-01-0-521	EG&G Contract No. EG&G-415-0-521
Checked by: J. B. LITTON Engineer DATE: PHS	EG&G Approved: R. H. JONES P.E.C. - Civil NYA				2 of 2

NOTE:  
REFER TO DRAWING TE-1-D-52  
PHS-MDM-101 AND EG-01-D-52  
SHEET 1 PHS-MDM-102 FOR  
INFORMATION ON AGENT  
COLLECTION SYSTEM



DETAIL A




DETAIL B



DETAILS

**REFERENCE DRAWINGS:**

EG-01-005114 HOB ACS PWS-HOB-103 ASSEMBLY  
EG-01-005102 SWT. 1 HOB ACS PWS-HOB-102 ASSEMBLY  
EG-01-00521 SWT. 2 HOB AGENT COLLECTION SYSTEM PWS-HOB-103 PIPE  
EG-01-00521 HOB AGENT COLLECTION SYSTEM PWS-HOB-101 PUMP  
EG-01-005101 SWT. 2 HOB ACS PWS-HOB-101 INSTALLATION DETAILS  
EG-01-005101 SWT. 3 HOB ACS PWS-HOB-101 GENERAL ARRANGEMENT  
EG-01-005115 SWT. 1 HOB ACS PWS-HOB-103 INSTALLATION DETAILS  
EG-01-005115 SWT. 2 HOB ACS PWS-HOB-103 PIPE SPOOLS DETAILS



<p> <b>BILL OF MATERIAL</b> </p>
----------------------------------

[illegible]

3b	REVISED FOR CONSTRUCTION	8/17/95	PK
3A	REVISED FOR CONSTRUCTION	8/17/95	PK
	REVISED AS BUILT	8/17/95	MS
2	REVISED FOR CONSTRUCTION	8/16/95	PK
1	REVISED FOR CONSTRUCTION	8/16/95	MS
0	ISSUED FOR CONSTRUCTION	11/27/94	PK
Symbol	Description	Date	Author




Revisions	
DEPARTMENT OF THE ARMY PROGRAM MANAGER FOR CHEMICAL DECONTAMINATION	US ARMY ENGINEER DISTRICT SACRAMENTO CORPS OF ENGINEERS SACRAMENTO, CALIFORNIA

**EG&G**  
A Division of UTC

Orlando, FL 32817  
Tel: 407/241-1000

EG&G is a Division of UTC

Checked by: J. SHUBERT	EG&G Approved: SG WILTON	Score:	Sheet reference number:	EG&G Contract No. DAC48-69-C-0076
Engineer: DR. CLARK	POC Mr. CONN N/A	NO. 4641	EG-01-M-5102	Sheet 2 of 2




Grouped Table									
SL	DATE	REVISION DESCRIPTION	ISSUED	CHK.	REV.	DATE	REV.	DATE	REV.
1	01/01/01	REVISED PER (NO 00-20445 & (P 3144	2001	21	2001				
2	01/01/01	REVISED PER (NO 00-00000000	2001	21	2001				
3	01/01/01	REVISED PER (NO 00-0019425	2001	21	2001				
4	01/01/01	REVISED PER (NO 00-20048 & (P 4214	2001	21	2001				
5	01/01/01	REVISED PER (NO 00000000	2001	21	2001				
6	01/01/01	REVISED PER (NO 001400 & (P 4333	2001	21	2001				
7	01/01/01	REVISED PER (NO 001400 & (P 4333	2001	21	2001				
8	01/01/01	REVISED PER (NO 001400 & (P 4333	2001	21	2001				
9	01/01/01	REVISED PER (NO 001400 & (P 4333	2001	21	2001				
10	01/01/01	REVISED PER (NO 001400 & (P 4333	2001	21	2001				

**NOTES:**


1. SEE DETAIL C FOR VENT DETAIL.
2. SEE DETAIL D FOR VENT DETAIL.
3. CHECK VALVES MUST BE INSTALLED IN A HORIZONTAL POSITION WITH THE DISC FLAT ON TOP. VERIFY ORIENTATION FOR CORRECT FLOW DIRECTION.
4. SEE DRAWING 2051-01-0-172 FOR DRAIN TIE ASSEMBLY.
5. SEE DRAWING EG-01-0-5113 FOR EXPLODED VIEW OF THE DRAIN ASSEMBLY.
6. TUBING AND NOSE PLUGS TO BE KEPT AS SHORT AS POSSIBLE WITH NO LOW POINTS TO COLLECT LIQUID.
7. PAINT PER SPEC: 099000.
8. FIELD MOUNT VALVES ON AOS SADD.
9. SOLD/LOOTS ARE MOUNTED TO ACTUATORS.
10. DRAIN TIE COES BETWEEN DRAIN BORE EXTENSION AND NOSE. SEE EG-01-0-5113 FOR EXPLODED VIEW.

BILL OF MATERIAL				
ITEM	DESCRIPTION	AMOUNT/ACTIVITY	PART NUMBER	QTY
1	MCALINE, WALK 10-00-00-0100			1
2	MCALINE, WALK 10-00-00-0100			1
3	MCALINE, WALK 10-00-00-0100			1
4	MCALINE, WALK 10-00-00-0100			1
5	MCALINE, WALK 10-00-00-0100			1
6	MCALINE, WALK 10-00-00-0100			1
7	MCALINE, WALK 10-00-00-0100			1
8	MCALINE, WALK 10-00-00-0100			1
9	MCALINE, WALK 10-00-00-0100			1
10	MCALINE, WALK 10-00-00-0100			1
11	MCALINE, WALK 10-00-00-0100			1
12	MCALINE, WALK 10-00-00-0100			1
13	MCALINE, WALK 10-00-00-0100			1
14	MCALINE, WALK 10-00-00-0100			1
15	MCALINE, WALK 10-00-00-0100			1
16	MCALINE, WALK 10-00-00-0100			1
17	MCALINE, WALK 10-00-00-0100			1
18	MCALINE, WALK 10-00-00-0100			1
19	MCALINE, WALK 10-00-00-0100			1
20	MCALINE, WALK 10-00-00-0100			1
21	MCALINE, WALK 10-00-00-0100			1
22	MCALINE, WALK 10-00-00-0100			1
23	MCALINE, WALK 10-00-00-0100			1
24	MCALINE, WALK 10-00-00-0100			1
25	MCALINE, WALK 10-00-00-0100			1
26	MCALINE, WALK 10-00-00-0100			1
27	MCALINE, WALK 10-00-00-0100			1
28	MCALINE, WALK 10-00-00-0100			1
29	MCALINE, WALK 10-00-00-0100			1
30	MCALINE, WALK 10-00-00-0100			1
31	MCALINE, WALK 10-00-00-0100			1
32	MCALINE, WALK 10-00-00-0100			1
33	MCALINE, WALK 10-00-00-0100			1
34	MCALINE, WALK 10-00-00-0100			1
35	MCALINE, WALK 10-00-00-0100			1
36	MCALINE, WALK 10-00-00-0100			1
37	MCALINE, WALK 10-00-00-0100			1
38	MCALINE, WALK 10-00-00-0100			1
39	MCALINE, WALK 10-00-00-0100			1
40	MCALINE, WALK 10-00-00-0100			1
41	MCALINE, WALK 10-00-00-0100			1
42	MCALINE, WALK 10-00-00-0100			1
43	MCALINE, WALK 10-00-00-0100			1
44	MCALINE, WALK 10-00-00-0100			1
45	MCALINE, WALK 10-00-00-0100			1
46	MCALINE, WALK 10-00-00-0100			1
47	MCALINE, WALK 10-00-00-0100			1
48	MCALINE, WALK 10-00-00-0100			1
49	MCALINE, WALK 10-00-00-0100			1
50	MCALINE, WALK 10-00-00-0100			1
51	MCALINE, WALK 10-00-00-0100			1
52	MCALINE, WALK 10-00-00-0100			1
53	MCALINE, WALK 10-00-00-0100			1
54	MCALINE, WALK 10-00-00-0100			1
55	MCALINE, WALK 10-00-00-0100			1
56	MCALINE, WALK 10-00-00-0100			1
57	MCALINE, WALK 10-00-00-0100			1
58	MCALINE, WALK 10-00-00-0100			1
59	MCALINE, WALK 10-00-00-0100			1
60	MCALINE, WALK 10-00-00-0100			1
61	MCALINE, WALK 10-00-00-0100			1
62	MCALINE, WALK 10-00-00-0100			1
63	MCALINE, WALK 10-00-00-0100			1
64	MCALINE, WALK 10-00-00-0100			1
65	MCALINE, WALK 10-00-00-0100			1
66	MCALINE, WALK 10-00-00-0100			1
67	MCALINE, WALK 10-00-00-0100			1
68	MCALINE, WALK 10-00-00-0100			1
69	MCALINE, WALK 10-00-00-0100			1
70	MCALINE, WALK 10-00-00-0100			1
71	MCALINE, WALK 10-00-00-0100			1
72	MCALINE, WALK 10-00-00-0100			1
73	MCALINE, WALK 10-00-00-0100			1
74	MCALINE, WALK 10-00-00-0100			1
75	MCALINE, WALK 10-00-00-0100			1
76	MCALINE, WALK 10-00-00-0100			1
77	MCALINE, WALK 10-00-00-0100			1
78	MCALINE, WALK 10-00-00-0100			1
79	MCALINE, WALK 10-00-00-0100			1
80	MCALINE, WALK 10-00-00-0100			1
81	MCALINE, WALK 10-00-00-0100			1
82	MCALINE, WALK 10-00-00-0100			1
83	MCALINE, WALK 10-00-00-0100			1
84	MCALINE, WALK 10-00-00-0100			1
85	MCALINE, WALK 10-00-00-0100			1
86	MCALINE, WALK 10-00-00-0100			1
87	MCALINE, WALK 10-00-00-0100			1
88	MCALINE, WALK 10-00-00-0100			1
89	MCALINE, WALK 10-00-00-0100			1
90	MCALINE, WALK 10-00-00-0100			1
91	MCALINE, WALK 10-00-00-0100			1
92	MCALINE, WALK 10-00-00-0100			1
93	MCALINE, WALK 10-00-00-0100			1
94	MCALINE, WALK 10-00-00-0100			1
95	MCALINE, WALK 10-00-00-0100			1
96	MCALINE, WALK 10-00-00-0100			1
97	MCALINE, WALK 10-00-00-0100			1
98	MCALINE, WALK 10-00-00-0100			1
99	MCALINE, WALK 10-00-00-0100			1
100	MCALINE, WALK 10-00-00-0100			1
101	MCALINE, WALK 10-00-00-0100			1
102	MCALINE, WALK 10-00-00-0100			1
103	MCALINE, WALK 10-00-00-0100			1
104	MCALINE, WALK 10-00-00-0100			1
105	MCALINE, WALK 10-00-00-0100			1
106	MCALINE, WALK 10-00-00-0100			1
107	MCALINE, WALK 10-00-00-0100			1
108	MCALINE, WALK 10-00-00-0100			1
109	MCALINE, WALK 10-00-00-0100			1
110	MCALINE, WALK 10-00-00-0100			1
111	MCALINE, WALK 10-00-00-0100			1
112	MCALINE, WALK 10-00-00-0100			1
113	MCALINE, WALK 10-00-00-0100			1
114	MCALINE, WALK 10-00-00-0100			1
115	MCALINE, WALK 10-00-00-0100			1
116	MCALINE, WALK 10-00-00-0100			1
117	MCALINE, WALK 10-00-00-0100			1
118	MCALINE, WALK 10-00-00-0100			1
119	MCALINE, WALK 10-00-00-0100			1
120	MCALINE, WALK 10-00-00-0100			1
121	MCALINE, WALK 10-00-00-0100			1
122	MCALINE, WALK 10-00-00-0100			1
123	MCALINE, WALK 10-00-00-0100			1
124	MCALINE, WALK 10-00-00-0100			1
125	MCALINE, WALK 10-00-00-0100			1
126	MCALINE, WALK 10-00-00-0100			1
127	MCALINE, WALK 10-00-00-0100			1
128	MCALINE, WALK 10-00-00-0100			1
129	MCALINE, WALK 10-00-00-0100			1
130	MCALINE, WALK 10-00-00-0100			1
131	MCALINE, WALK 10-00-00-0100			1
132	MCALINE, WALK 10-00-00-0100			1
133	MCALINE, WALK 10-00-00-0100			1
134	MCALINE, WALK 10-00-00-0100			1
135	MCALINE, WALK 10-00-00-0100			1
136	MCALINE, WALK 10-00-00-0100			1
137	MCALINE, WALK 10-00-00-0100			1
138	MCALINE, WALK 10-00-00-0100			1
139	MCALINE, WALK 10-00-00-0100			1
140	MCALINE, WALK 10-00-00-0100			1
141	MCALINE, WALK 10-00-00-0100			1
142	MCALINE, WALK 10-00-00-0100			1
143	MCALINE, WALK 10-00-00-0100			1
144	MCALINE, WALK 10-00-00-0100			1
145	MCALINE, WALK 10-00-00-0100			1
146	MCALINE, WALK 10-00-00-0100			1
147	MCALINE, WALK 10-00-00-0100			1
148	MCALINE, WALK 10-00-00-0100			1
149	MCALINE, WALK 10-00-00-0100			1
150	MCALINE, WALK 10-00-00-0100			1
151	MCALINE, WALK 10-00-00-0100			1
152	MCALINE, WALK 10-00-00-0100			1
153	MCALINE, WALK 10-00-00-0100			1
154	MCALINE, WALK 10-00-00-0100			1
155	MCALINE, WALK 10-00-00-0100			1
156	MCALINE, WALK 10-00-00-0100			1
157	MCALINE, WALK 10-00-00-0100			1
158	MCALINE, WALK 10-00-00-0100			1
159	MCALINE, WALK 10-00-00-0100			1
160	MCALINE, WALK 10-00-00-0100			1
161	MCALINE, WALK 10-00-00-0100			1
162	MCALINE, WALK 10-00-00-0100			1
163	MCALINE, WALK 10-00-00-0100			1
164	MCALINE, WALK 10-00-00-0100			1
165	MCALINE, WALK 10-00-00-0100			1
166	MCALINE, WALK 10-00-00-0100			1
167	MCALINE, WALK 10-00-00-0100			1
168	MCALINE, WALK 10-00-00-0100			1
169	MCALINE, WALK 10-00-00-0100			1
170	MCALINE, WALK 10-00-00-0100			1
171	MCALINE, WALK 10-00-00-0100			1
172	MCALINE, WALK 10-00-00-0100			1
173	MCALINE, WALK 10-00-00-0100			1
174	MCALINE, WALK 10-00-00-0100			1
175	MCALINE, WALK 10-00-00-0100			1
176	MCALINE, WALK 10-00-00-0100			1
177	MCALINE, WALK 10-00-00-0100			1
178	MCALINE, WALK 10-00-00-0100			1
179	MCALINE, WALK 10-00-00-0100			1
180	MCALINE, WALK 10-00-00-0100			1
181	MCALINE, WALK 10-00-00-0100			1
182	MCALINE, WALK 10-00-00-0100			1
183	MCALINE, WALK 10-00-00-0100			1
184	MCALINE, WALK 10-00-00-0100			1
185	MCALINE, WALK 10-00-00-0100			1
186	MCALINE, WALK 10-00-00-0100			1
187	MCALINE, WALK 10-00-00-0100			1
188	MCALINE, WALK 10-00-00-0100			1
189	MCALINE, WALK 10-00-00-0100			1
190	MCALINE, WALK 10-00-00-0100			1
191	MCALINE, WALK 10-00-00-0100			1
192	MCALINE, WALK 10-00-00-0100			1
193	MCALINE, WALK 10-00-00-0100			1
194	MCALINE, WALK 10-00-00-0100			1
195	MCALINE, WALK 10-00-00-0100			1
196	MCALINE, WALK 10-00-00-0100			1
197	MCALINE, WALK 10-00-00-0100			1
198	MCALINE, WALK 10-00-00-0100			1
199	MCALINE, WALK 10-00-00-0100			1
200	MCALINE, WALK 10-00-00-0100			1
201	MCALINE, WALK 10-00-00-0100			1
202	MCALINE, WALK 10-00-00-0100			1
203	MCALINE, WALK 10-00-00-0100			1
204	MCALINE, WALK 10-00-00-0100			1
205	MCALINE, WALK 10-00-00-0100			1
206	MCALINE, WALK 10-00-00-0100			1
207	MCALINE, WALK 10-00-00-0100			1
208	MCALINE, WALK 10-00-00-0100			1
209	MCALINE, WALK 10-00-00-0100			1
210	MCALINE, WALK 10-00-00-0100			1
211	MCALINE, WALK 10-00-00-0100			1
212	MCALINE, WALK 10-00-00-0100			1
213	MCALINE, WALK 10-00-00-0100			1
214	MCALINE, WALK 10-00-00-0100			1
215	MCALINE, WALK 10-00-00-0100			1
216	MCALINE, WALK 10-00-00-0100			1
217	MCALINE, WALK 10-00-00-0100			1
218	MCALINE, WALK 10-00-00-0100			1
219	MCALINE, WALK 10-00-00-0100			1
220	MCALINE, WALK 10-00-00-0100			1
221	MCALINE, WALK 10-00-00-0100			1
222	MCALINE, WALK 10-00-00-0100			1
223	MCALINE, WALK 10-00-00-0100			1
224	MCALINE, WALK 10-00-00-0100			1
225	MCALINE, WALK 10-00-00-0100			1
226	MCALINE, WALK 10-00-00-0100			1
227	MCALINE, WALK 10-00-00-0100			1
228	MCALINE, WALK 10-00-00-0100			1
229	MCALINE, WALK 10-00-00-0100			1
230	MCALINE, WALK 10-00-00-0100			1
231	MCALINE, WALK 10-00-00-0100			1
232	MCALINE, WALK 10-00-00-0100			1
233	MCALINE, WALK 10-00-00-0100			1
234	MCALINE, WALK 10-00-00-0100			1
235	MCALINE, WALK 10-00-00-0100			1
236	MCALINE, WALK 10-00-00-0100			1
237	MCALINE, WALK 10-00-00-0100			1
238	MCALINE, WALK 10-00-00-0100			1
239	MCALINE, WALK 10-00-00-0100			1
240	MCALINE, WALK 10-00-00-0100			1
241	MCALINE, WALK 10-00-00-0100			1
242	MCALINE, WALK 10-00-00-0100			1
243	MCALINE, WALK 10-00-00-0100			1
244	MCALINE, WALK 10-00-00-0100			

70	REVISED FOR CONSTRUCTION	8/27/98	PK
7A	REVISED FOR CONSTRUCTION	8/21/98	PK
7	REVISED AS BUILT	8/21/98	NS
8	REVISED FOR CONSTRUCTION	8/21/98	NS
5	REVISED FOR CONSTRUCTION	8/27/98	NS
4	REVISED FOR CONSTRUCTION	8/27/98	NS
3	REVISED FOR CONSTRUCTION	10/27/98	NS
2	REVISED FOR CONSTRUCTION	10/27/98	NS
Symbol	Description	Date	Approved
	revision		

DEPARTMENT of the Army PROGRAM MANAGER for CHEMICAL DEMILITARIZATION ARMED PROTECTING, DURING, AND  A Division of UTES		US ARMY ARMED DISTRICT SACRAMENTO COMPS of ENGINEERS SACRAMENTO, CALIFORNIA	
50 Army Corps Engineers		10000 ARMY DEP 10000-01	
CHEMICAL STOCKPILE DISPOSAL PROGRAM MUNITIONS DEMILITARIZATION BUILDING ACS PHS-ARM-102 <b>ASSEMBLY</b>		10000-01 10000-01	
Design Sys 50 BIDDINGS	08/21/78	Scores	Short Performance number 1
Checked by 50 APLTIN	50 AGO Approved 01 JUL 50	NO SCALE	50 AGO Contract No. 10000-01-0001
Engineer PHS-ARM-102	01 JUL 50		10000-01-0001



CHART 1

NOTES:

1. FROTH COLLECTION PARTS SHOWN ARE FOR THE 4.2 MORTAR. PARTS FOR THE OTHER MUNITIONS ATTACH AND OPERATE IN THE SAME MANNER USING THE SAME HARDWARE.
2. RETAIN PARTS AND HARDWARE REMOVED FOR INSTALLATION OF THE FROTH PARTS FOR POSSIBLE REUSE WHEN OPERATING WITHOUT FROTH COLLECTION.
3. THE FROTH FRAMC SPACER, FIND 1, IS USED IN TWO PLACES WHENEVER FROTH COLLECTION PARTS ARE IN PLACE.
4. FRAMC SPACER (COSI-M-45-9002) IS USED IN ADDITION TO ITEM 1 WHEN PROCESSING H10 AND H210 PRODUCTS.
5. FLEXIBLE HOSE (FIND 7) CONNECTS WITH THE FROTH COLLECTION FITTING OF THE MDM PDS BRP PAN VALVE MANIFOLD, DRAFT 54-0006.
6. REFER TO CBTF DRAWING NUMBER AOS-0018 FOR MDM SYSTEM PLID INFORMATION.

104	REVISED FOR CONSTRUCTION FOR EWP 103740 & ECP 438712/4740	PLP	FLW/PLTC
10A	REVISED FOR CONSTRUCTION FOR EWP 103740 & ECP 438712/4740	PLP	FLW/PLTC
NO	ECP	REVISIONS	DATE BY APPR

**TOLERANCES**

ALL DIMENSIONS IN INCHES


X: ± .010    X ± 1/8 ± 1/16

Y: ± .003    1/16: ± 1/32

XXX: ± .0005    1/32: ± 1/64

ANGULAR: ± 1'    1/64

UNLESS OTHERWISE NOTED



CHEMICAL DEMILITARIZATION  
TRAINING FACILITY

ASSEMBLY DRAWING  
FROTH COLLECTION  
MDM

**GENERAL PHYSICS CORPORATION**  
Test & Eval Group  
PO Box 38, Bldg. 5-45M1  
APG-AE MD 21010-0038

DRAWN BY: DWW	DATE: 10/27/74	REV: A
CHECKED BY: JRB		

SHEET NO.	SCALE:	DRAWING NO:
1 OF 1	1:2 (D SIZE)	45-0221






4


3

2


1



PARTS LIST					
ITEM NO.	QTY	UNIT	DESCRIPTION	PART NO.	MATERIAL OR MFG.
1	1	EA	MIL 4.2 X 2.25M	45-0287-1	HR 4130 STL



SECTION A-A



## NOTES:

1. HARDEN TO Rc 43 TO 46
2. FINISH 14.3.1, 0.0008 THICK, MIL-STD-171-0
3. SOME HIDDEN LINES OMITTED FOR CLARITY
4. ALL MACHINED SURFACES TO BE 125 RMS OR BETTER




B	-	ISSUED	11/25/04	DMV	JML
A	-	REDESIGNED PART	10/25/04	DMV	JML
-	-	ISSUE	3/5/03	SPR	
NO	EP#	REVISIONS	DATE	BY	APPROV
TOLERANCES					
ALL DIMENSIONS IN INCHES					
X: ± 0.1 Y: ± 0.005 Z: ± 0.005					
XX: ± 0.03 YY: ± 0.003 ZZ: ± 0.003					
XXX: ± 0.005 YYY: ± 0.003 ZZZ: ± 0.003					
ANGULAR: ± 1.0° ± 0.5° ± 0.25°					
UNLESS OTHERWISE NOTED					
CHEMICAL DEMILITARIZATION TRAINING FACILITY			MODIFIED STOP PLATE 4.2 MORTAR PROTH COLLECTION SYSTEM MDM PUNCH & DRAIN STATION		
GENERAL PRACTICE CORPORATION			DRAWN BY: SPR DATE: 14 FEB 2003		
Test & Eval Group			CHECKED BY: JWB		
PO Box 58, Bldg. E-45M1			SHEET NO. 1 OF 1		
APG-EA, MD 21010-0038			SCALE: 1:2 C DWG		
			DRAWING NO: 45-0287		

4

3

2


1



① FROTH DAM

NOTES: (FINDS 1 & 2)

1. SOME HIDDEN LINES ARE OMITTED FOR CLARITY
2. REMOVE ALL BURRS AND SHARP EDGES.
3. CLEAN ALL WELDS IF FABRICATED
4. FINISH 14.31, 0.0008 THICK, MIL-STD-171-0.



② CYLINDER HANGER - FROTH

(REF) 3051-45-M-7703, CYLINDER HANGER

PARTS LIST					
FIND NO	QTY	UNIT	NOMENCLATURE	PART NO	MATERIAL OR MFG
1	EA		FROTH DAM	45-0321-1	1020 HRS
2	EA		CYLINDER HANGER-FROTH	45-0321-2	ASTM 1020

EG&G  
10A

NO	DESCRIPTION	DATE	BY	APPROV
10A	REVISED FOR CONSTRUCTION PER EWO 103740 & ECP 4333			
D	ISSUED	11/05/04	DWH	JAL
C	DRAWING NUMBER WAS 45-0218	11/04/04	DWH	JAL
B	DWG WAS "C" SIZE - ADDED FIND 2 - ADDED NOTES 1-4	10/22/04	DWH	JAL
A	MATERIAL FOR FIND 1 WAS 316 SS.	4/30/01	JAL	

TOLERANCES		REVISIONS	
ALL DIMENSIONS IN INCHES			
X: * 0.1	X ≥ 1/8: * 1/16		
XX: * 0.03	1/16: * 1/32		
XXX: * 0.005	1/32: * 1/64		
ANGULAR: * 1°			
UNLESS OTHERWISE NOTED			


**CHEMICAL DEMILITARIZATION  
TRAINING FACILITY**

**FROTH DAM AND  
FROTH CYLINDER HANGER  
MDM**

DRAWN BY: DWH		DATE: 102004		REV. D	
CHECKED BY: JRB					


**GENERAL PHYSICS CORPORATION**  
Test & Eval Group  
PO Box 38, Bldg E-45M  
APG-PA, MD 21010-0038

SHEET NO. 1 OF 1		SCALE: 1:1 (D SIZE)		DRAWING NO. 45-0321	
------------------	--	---------------------	--	---------------------	--



Ⓜ A Ⓜ B 0.001 ⊥ C 0.010  
 Ø0.413 1 PLACE NEAR SIDE  
 2 PLACES FAR SIDE

Ⓜ A Ⓜ B 0.001 Ⓜ B 0.020 ⊥ C 0.010




DETAILS OF SLOT  
 NEAR SIDE ONLY

- NOTES:
1. FINISH 14.3.1, 0.0008 THICK, MIL-STD-171-0.
  2. REMOVE ALL BURRS AND SHARP EDGES.
  3. SOME HIDDEN LINES ARE OMITTED FOR CLARITY

PARTS LIST				
PART NO.	QTY	UNIT	DESCRIPTION	MATERIAL OR MFG.
1	1	EA	FROTH SHIELD, M2/A1 MORTAR	45-0329-1 1020 HRS

ISSUED		11/05/04		DWV	JNL
NO.	EDP	REVISIONS	DATE	BY	APRV
TOLERANCES			CHEMICAL DEMILITARIZATION TRAINING FACILITY		
ALL DIMENSIONS IN INCHES			MDM FROTH SHIELD FOR 4.2 MORTAR		
.X: ± 0.1 .XX: ± 0.03 .XXX: ± 0.005 ANGULAR: ± 1° UNLESS OTHERWISE NOTED			DRAWN BY: DWV CHECKED BY: JRB DATE: 10/22/04 SCALE: 1:1 (D SIZE) SHEET NO. 1 OF 1 DRAWING NO. 45-0329		
GENERAL PHYSICS CORPORATION Test & Eval Group PO Box 38, Bldg E-45M1 APC-EA, MD 21010-0038					



# NOTES:

1. PREPARE ALL SURFACES IN ACCORDANCE WITH THE GENERAL REQUIREMENTS OF MIL-STD-171D. APPLY ONE COAT OF EPOLOID 7-W-20 PRIMER 0.002 INCHES THICK FOLLOWED BY TWO COATS OF EPOLOID 5-G-12 COLOR GREEN, 0.002 INCHES THICK MINIMUM, EACH COAT IN ACCORDANCE WITH MANUFACTURERS INSTRUCTIONS.

ROWE PRODUCTS INC.  
NIAGARA FALLS, NY; MFG. NO. 77949

2. PRESS PIN AFTER PAINTING
3. SOME HIDDEN LINES OMITTED FOR CLARITY

B		ISSUED	11/05/04	DWV	JML
A		DRAWING WAS "C" SIZE	10/22/04	DWV	JML
NO	EDP	REVISIONS	DATE	BY	APRY
<p><b>TOLERANCES</b></p> <p>ALL DIMENSIONS IN INCHES</p> <p>X: ± 0.1 X ≥ 1/8 ± 1/16</p> <p>X6: ± 0.03 1/16: ± 1/32</p> <p>X00: ± 0.005 1/32: ± 1/64</p> <p>ANGULAR: ± 1°</p> <p>UNLESS OTHERWISE NOTED</p>					
<p>CHEMICAL DEMILITARIZATION TRAINING FACILITY</p> <p>FRAME SPACER FOR FROTH COLLECTION MDM PUNCH AND DRAIN STATION</p>					
GENERAL INDUSTRIES CORPORATION		DRAWN BY: DWV	DATE:	REV.	
Test & Eval Group		CHECKED BY: JRB	10/19/04	B	
PO Box 38, Bldg. E-45M1		SHEET NO.	SCALE:	DRAWING NO.	
APC-EA, MD 21010-0038		1 OF 1	1:1 (D SIZE)	45-0324	

**G: NOTICE TO MAILING LIST AND NEWSPAPER PUBLISHER**

REQUEST NUMBER: TOCDF-MDM-02-0836

REQUEST TITLE: Froth Collection system for MDMs

SUMMARY: TOCDF has completed destruction of warfare munitions containing GB (Sarin) and VX. TOCDF is now in the process of modifying plant equipment for the processing of munitions containing the chemical warfare agents designated as H, HD and HT (collectively referred to as "Mustard" blister agent). The Mustard "campaign" is the third and final agent demilitarization campaign TOCDF is to undertake.

The Deseret Chemical Depot's chemical weapons stockpile contains approximately 63,500 4.2-inch mortars containing Mustard. Experience with Mustard-containing 4.2-inch mortars at the Johnston Atoll demilitarization site (JACADS) has shown that the liquid Mustard within the mortars may have experienced age-related internal pressurization. Mortars will be treated at TOCDF during the Non-Baseline Mustard campaign.

At JACADS many of the 4.2-inch mortars experienced "frothing" or foaming of their liquid contents when the agent cavity was breached. This resulted in some Mustard froth bubbling up and out of the mortars and onto the mortar body and surrounding machinery. In an effort to reduce the potential for agent contamination of TOCDF machinery and room surfaces, a "froth collection system" was designed to be installed on the Multipurpose Demilitarization Machines (MDMs) pull and drain station, where the 4.2-inch mortars will be processed. None of the munitions previously treated at the TOCDF MDMs exhibited a tendency to froth.

Concurrent with this modification request, TOCDF is requesting temporary authorization (TA) to begin installation and testing activities associated with the MDMs' 4.2-inch mortar froth collection systems prior to the end of the 60-day post-submittal period. The MDMs will not be used for hazardous waste treatment under the requested TA.